



MEEK MIRRORS, LLC
PO Box 11200
Fort Smith, Arkansas 72917-1200
800-643-2533 Fax 479-646-6231
www.meekmirrors.com

Installation Instructions

SNAP ANGLE FRAME	DATE 2/2010	MODEL M1100 M1110 M1200 M1210	SHEET NO. 1-00
------------------	----------------	-------------------------------------	-------------------

Installation Instructions

- 1) Disassemble frame from back plate.
- 2) Mount back plate to the wall using screw holes closest to the roll formed edge. Make sure the back plate is level and square.
- 3) Position mirror on the bottom edge of the back plate with mirror resting on the roll formed flange and hold in place. Make sure the mirror is firmly in the frame.
- 4) Starting at the bottom of the frame, place the frame over the edge of the back plate. Start to snap the frame onto the back plate working toward the corners. Then continue up the sides and across the top until the frame snaps in place.

Product made in the USA.

