



6201 S ZERO ST
FORT SMITH, AR

800-643-2533
MEEKMIRRORS.COM

ANGLE FRAMED MIRROR M1100 & M1200 SERIES

INSTALLATION

JULY 2017

INSTALLATION INSTRUCTIONS

1. DISASSEMBLE FRAME FROM WALL PLATE BY INSERTING SCREWDRIVER UNDER EDGE OF FRAME AND SEPARATE FRAME FROM WALL PLATE.
2. MOUNT WALL PLATE TO THE WALL USING PRE-DRILLED SCREW HOLES CLOSEST TO THE ROLL FORMED EDGE. MAKE SURE THE WALL PLATE IS LEVEL AND SQUARE.
3. POSITION MIRROR IN CENTER OF WALL PLATE AND HOLD FIRMLY.
4. STARTING AT THE BOTTOM OF THE FRAME, PLACE THE FRAME OVER THE EDGE OF THE WALL PLATE. START TO SNAP THE FRAME ONTO THE WALL PLATE WORKING TOWARD THE CORNERS. THEN CONTINUE UP THE SIDES AND ACROSS THE TOP UNTIL THE FRAME "SNAPS" IN PLACE.
5. TO REMOVE, PLACE "L" SHAPE TOOL UNDER EDGE OF FRAME AND START SEPARATING UNTIL FRAME UNSNAPS.

PRODUCT MADE IN THE USA.

