



**MEEK MIRRORS, LLC**  
PO Box 11200  
Fort Smith, Arkansas 72917-1200  
800-643-2533 Fax 479-646-6231  
[www.meekmirrors.com](http://www.meekmirrors.com)

**Installation  
Instructions**

CONTEMPORARY FRAMED MIRROR	DATE JUNE 2017	MODEL M1360
-------------------------------	-------------------	----------------

## Installation Instructions

- 1) Install wall plate on wall. Fasten all four corners. Recheck to make sure back plate is square and level.
- 2) Center framed mirror over the wall plate. Slide the mirror completely down to the hook. Check all four corners to ensure they are fastened to the wall plate.
- 3) Pull string toward the corner to engage the lock. After the final inspection cut and remove the string.

Product made in the USA.

