



6201 S ZERO ST
FORT SMITH, AR

800-643-2533
MEEKMIRRORS.COM

CHANNEL FRAMED MIRROR M1500 & M1510 SERIES

INSTALLATION

AUGUST 2017

INSTALLATION INSTRUCTIONS

1. INSTALL WALL PLATE ON WALL. FASTEN ALL FOUR CORNERS USING THE PRE-DRILLED HOLES. RECHECK TO MAKE SURE WALL PLATE IS SQUARE AND LEVEL.
2. CENTER FRAMED MIRROR OVER THE WALL PLATE. SLIDE THE MIRROR COMPLETELY DOWN ON THE LUGS. CHECK ALL FOUR CORNERS TO ENSURE THEY ARE FASTENED TO THE WALL PLATE.
3. PULL STRING TOWARD THE RIGHT CORNER TO ENGAGE THE SECURITY LOCK. AFTER THE FINAL INSPECTION, CUT AND REMOVE THE STRING.
4. TO REMOVE MIRROR: INSERT PUTTY KNIFE AT BOTTOM RIGHT SIDE AND PUSH SECURITY LOCK BACK TO THE LEFT. LIFT UP AND REMOVE.

PRODUCT MADE IN THE USA.

