



6201 S ZERO ST
FORT SMITH, AR

800-643-2533
MEEKMIRRORS.COM

ADA SOLID FIXED TILT MIRROR M4300 & M4400 SERIES

INSTALLATION

JULY 2017

INSTALLATION INSTRUCTIONS

1. DISASSEMBLE FRAME FROM WALL PLATE BY INSERTING SCREWDRIVER UNDER EDGE OF FRAME AND SEPARATE FRAME FROM WALL PLATE.
2. MOUNT WALL PLATE TO THE WALL USING PRE-DRILLED SCREW HOLES. MAKE SURE THE BACK PLATE IS LEVEL AND SQUARE.
3. POSITION MIRROR AND CARDBOARD ON THE BOTTOM EDGE OF THE WALL PLATE AND HOLD IN PLACE. MAKE SURE THE MIRROR IS HELD FIRMLY IN THE FRAME.
4. STARTING AT THE BOTTOM OF THE FRAME, PLACE THE FRAME OVER THE EDGE OF THE WALL PLATE. START TO SNAP THE FRAME ONTO THE BACK PLATE WORKING TOWARD THE CORNERS. THEN CONTINUE UP THE SIDES AND ACROSS THE TOP UNTIL THE FRAME SNAPS IN PLACE.

PRODUCT MADE IN THE USA.

