Check out some of our other products





M2011, M4011, M3010, M1011 LED Lighted Backlit Mirrors

U. S. A.

M1400TS/M1400TRIBL Wood Frame Mirrors

VOSB

To see Meek's other mirror styles , shelves and restroom accessories visit our website!

www.meekmirrors.com





Owners Care Manual



M1100/1200 Angle Frame Mirrors



Cleaning Instructions:

- 1. The best and safest cleaner for a mirror is clean, warm water used with a soft, lint-free cloth. Be careful to not allow the edges of the mirror to become wet over a period of time.
- 2. Never spray any cleaner directly onto the mirror. Instead apply the cleaner to the soft cloth and then wipe the mirror. This will also prevent "puddling" at the mirror edge where the cleaner could attack the backing.
- 3. If that does not work, use commercial cleaner that does not contain ammonia, vinegar, acid or alkali cleaner. All of these can attack the surface edges and back of the mirror resulting in black edge.
- 4. Do not use acid or alkali cleaners for the mirror after installation. They can attack both the surface and the edges of the mirror. And NEVER use abrasive cleaner on any mirror surface.
- 5. Remove any surface marks or stubborn dirt with 0000 oil-free steel wool, not solvents. Solvents attack and damage edges and backing.
- 6. Always use soft grit free cloths when cleaning a mirror to reduce chances of scratching the surface.
- 7. Be sure to dry all joints and edges thoroughly to be certain that no commercial cleaner comes in contact with the edge and backing.

Warranty Information:

NOTE: <u>Improper Cleaning or Installation will void the warranty.</u> Visit our website to view full warranty information or scan the QR code on your smart phone.



QR Code Reader:

QR Code Readers can be downloaded to any IPhone or Android Phone. For IPhone users: go to the App Store on your phone and search QR Code Reader. For Android users: go to your phones Google Play or Android App Store and search for QR Code readers.

Installation Instructions:

1. Disassemble frame from wall plate by inserting screwdriver, putty knife, or painters tool under edge of frame and separate frame from wall plate.

2. Mount wall plate to the wall using pre-drilled screw holes closest to roll formed edge. Make sure the wall plate is level and square.

3. Position mirror in the center of the wall plate and hold firmly.

4. Starting at the bottom of the frame, place the frame over the edge of the corners then continue up the sides and across the top until the frame "SNAPS" into place.

5. To remove, place "L" shape tool under the edge of the frame and start separating until the frame unsnaps.



Installation Videos:

Visit our website www.meekmirrors.com to view installation videos *Scan the QR code to view them on your smart phone*

