



Step 1. Level and attach cleat to wall.

Step 2. Hang panel body on cleat and hardwire electrical.

Step 3. Take mirror and hang on panel body.